

LOADING TOOL PROCEDURE

SC73472, SC760, SC761 and SC50T

1. Pull pusher off the back end of the magazine and place onto hook on spring spool bracket.
2. Remove strip of fasteners from box.
3. Turn the strip of fasteners so that the fastener's opening is facing away from the tool.
4. Insert the magazine into the strip of fasteners and slide the strip of fasteners completely onto the magazine.
5. Place pusher back onto magazine behind

Optional method except for the SC50T: Pull pusher off the back end of the magazine and place onto hook on spring spool bracket. Fasteners can be loaded onto the magazine by turning tool so that the magazine is down toward the box, guide the magazine into a strip of fasteners, and slide the fasteners completely onto magazine. Place pusher back onto magazine behind the fasteners.

SC742, SC743, SC743SG, SC7, SC7C, SC7E and SC77XE

1. Remove strip of fasteners from box.
2. Turn the strip of fasteners so that the fastener's opening is facing away from the tool.
3. Insert the magazine into the strip of fasteners and slide the strip of fasteners pass the anti-backup clip.
4. Using two fingers pull the pusher back to the end of the magazine behind the fasteners.