




GLF 460




NO.200 Housing Assembly
23,27,28



NO.203 Frame Assembly
20,35R,35L,36,37,86




NO.201 Assembly
12,29,30,31,32,47,48,49,89




NO.205 Pusher Assembly
68,69



NO.106 Assembly
64,67,70,205,207



NO.206 Steel Magazine Assembly
73,75,76,77



NO.202 Assembly
47,48,49



ITEM	DESCRIPTION	MODEL	PART NO.	Q'TY
1	Set Screw		01001	1
3	Shakeproof Lock Washer		01003	7
4	Air Deflector		01004	1
5	Rear Valve Seat		01005	1
6	O-Ring		01006-NP	5
7	Throttle Spring		01007	1
8	Throttle Spring Locator		01008	1
9	Throttle Spring		01009	2
10	Throttle Spring Locator		01010	2
11	O-Ring Support		01011	4
12-1	O-Ring		01012-1-NP	5
13	O-Ring Center Support		01013	2
14	Throttle Valve Spacer		01014	1
16	Front Valve Seat		01016	1
17	Throttle Stem		01017	1
18	Button Head Cap Screw		01018	1
20	Trigger Guard		01020	1
21	Flexloc Nut		01021	2
23	Stud		01023	2
27	Housing		01C027	1
28	Set Screw		01028	2
29	O-Ring		01029-NP	1
30	Piston		01030	1
31	Cylinder Gasket		01031	1

ITEM	DESCRIPTION	MODEL	PART NO.	Q'TY
32	Piston Stop Spacer	01BK	01032	1
35R	Side Plate (Right)		0135R	1
35L	Side Plate (Left)		0135L	1
36	Roll Pin		01036	3
37	Trigger		01037	1
39	Socket Head Cap Screw		01039	4
40	Upper Jaw (Closure3~4mm)	01BK	01040	1
	Upper Jaw (Closure4~5mm)	01BL	01A040	
41	Jaw Bushing		01041	2
43	Latch Pin Clip		01043	1
44	Latch Spring		01044	1
45	Latch		01045	1
46	Roller		01046	4
47	Feeder Blade		01047	1
48	Piston Rod		01048	1
49	Roller Pin		01049	2
50	Lower Jaw (Closure3~4mm)	01BK	01050	1
	Lower Jaw (Closure4~5mm)	01BL	01A050	
51	Feeder Arm		01051	1
56	Washer		01056	4
57	Nut		01057	2
58	Screw		01058	2
59	Inlet Bushing		01059-1	1
64	Socket Head Cap Screw		01064	1

ITEM	DESCRIPTION	MODEL	PART NO.	Q'TY
67	Nut		01067	1
68	Pusher		601068	1
69	Extruded Rivet		01069	1
70	Pusher Spring		01070	1
71	Button Head Screw		01071	1
73	Steel Magazine Body		01073	1
74	Jaw Bolt		01074	2
75	Magazine Spring		01075	1
76	Magazine Shoe		01076	1
77	Roll Pin		01077	1
78	Magazine Shim		01078	1
78A	Magazine Shim		01078A	1
79	Washer		01079	2
86	Plate Screw		01086	1
89	Nut		01089	3
106	Feeder Guide Rail & Pusher Spring Assy.		01DE106	1
200	Housing Assy.		01C200	1
201	Assembly		01201	1
202	Piston Rod Assy.		01202	1
203	Side Plate Assy.		01203	1
205	Pusher Assy.		601205	1
206	Steel Magazine Assembly		01206	1
207	Feeder Guide Rail		01207	1